



**Features:**

- Available as fridge or freezer
- Adjustable thermostat
- Door lock
- 3.5 in. of Polyurethane Insulation
- Basket for food organization
- Scratch resistant galvanized steel exterior
- Easy to clean aluminum interior with drain
- Automatic 12 or 24VDC operation
- Simple design for worldwide service
- 1-year limited warranty

**MSRP \$799**  
*1-Year Limited Warranty*  
 (PV not included)

**Off-Grid DC  
 Refrigerator or Freezer**  
*Alternative to Propane Refrigeration*

Since 1999, SunDanzer Refrigeration has designed and assembled solar refrigerators in the United States. With DC power, no inverter is needed, which provides more reliable refrigeration. The SunLite product line was developed to provide a lower cost unit, with less features and less insulation. The SunLite model is ideal if energy consumption is not critical. Also, because freezers use about 3 times more energy than refrigerators, the SunLite models are better suited to be used as refrigerators, but they still work great as freezers.

**Applications:**

- Off-grid homes
- Remote stores
- Disaster preparedness
- Unreliable grid power
- Micro-enterprises
- Medical clinics
- Farms & ranches
- Missionary homes

**Specifications:**

Volume	5.4 ft <sup>3</sup> [154 L]
Refrigerator	34-45° F
Freezer	5-15° F
Ambient range	32 to 110° F
Refrigerator in 90° F	240 Wh/d
Freezer in 90° F	750 Wh/d
Input Voltage	12 or 24 VDC
Input Power	40-80 Watts
Refrigerant	R134a
Defrost	Manual
Dimensions (HWD)	32.5x35.3x24.5 in.