



Features:

- Available as fridge or freezer
- Adjustable thermostat
- Door lock
- 3.5 in. of Polyurethane Insulation
- Basket for food organization
- Scratch resistant galvanized steel exterior
- Easy to clean aluminum interior with drain
- Automatic 12 or 24VDC operation
- Simple design for worldwide service
- 1-year limited warranty

MSRP \$1799
 1-Year Limited Warranty
 (PV not included)

**Off-Grid DC
 Refrigerator or Freezer**
Alternative to Propane Refrigeration

Since 1999, SunDanzer Refrigeration has designed and assembled solar refrigerators in the United States. With DC power, no inverter is needed, which provides more reliable refrigeration.

Applications:

- Off-grid homes
- Remote stores
- Disaster preparedness
- Unreliable grid power
- Micro-enterprises
- Medical clinics
- Farms & ranches
- Missionary homes

Specifications:

Volume	8.4 ft ³ [238 L]
Refrigerator	34-45° F
Freezer	5-15° F
Ambient range	32 to 110° F
Refrigerator in 90° F	300 Wh/d
Freezer in 90° F	938 Wh/d
Input Voltage	12 or 24 VDC
Input Power	40-80 Watts
Refrigerant	R134a
Defrost	Manual
Dimensions (WxDxH)	40.75 x 29.5 x 33.5 inches